

Quick Guide for Attaching Geoid in Viva / SmartWorx 1200

In Viva:

1. -Transfer desired Geoid file to Internal Memory or Card in Geoid directory:
Int mem: Leica_Geosystems/Smartworx/Data/GPS/Geoid
Card: Data/GPS/Geoid
2. In data collector go to the Main Menu then 2 Jobs & Data:
-Select Job Properties and go to Coordinate Systems tab
-Choose desired coordinate system (or create new one) and press
F3 Edit. Scroll down to Geoid File field and press Enter key. Select the
New/desired Geoid file from selection (may need to choose from Int Mem/Card
via F6 key). Press F1 Store.

In 1200 SmartWorx,

1. Transfer desired Geoid file to Internal Memory or Card in Geoid directory (Data/GPS/Geoid)
2. In Smartworx go to Main Menu then to 3 Coordinate Systems.
3. Choose desired coordinates system and press F3 Edit. Scroll down to Geoid file field and press ENTER key. Select new/desired Geoid file and press F1 Store.
- 4.